AIRBUTLER®
Homecare

User manual

Electronic ioniser for refrigerator

Attention! Do not touch the needles when unit turned on!

Function:

By the combination of three of the world's most recognized technologies of purification, **AIRBUTLER** Philip is able to guarantee a maximum of purification: dust purification, removal of bacteria and elimination of nasty odours. All that can be achieved by a very powerful generator of ions. It produces negatively charged ions, which are able to destroy virus and mites. The power consumption is only 1,5 W. The produced active oxygen is in the position to purify air, to eliminate smoke and neutralize bad smells.

Well-being effect:

AIRBUTLER Philip removes smells and bacteria as well as fungus spore and-germs from the refrigerator. Fruits and vegetables stay fresh longer.

Low-noise construction:

AIRBUTLER Philip works without fan and is silently.

Applicable areas:

The application area of **AIRBUTLER** Philip is: refrigerators, bins and dishwashers (dishwasher has to be turned off!).

PHILIP

Start-up:
Open the battery compartment on the side of the device and insert following batteries:

- either 3 x D# alkaline battery – shelf life about 3 months
- or 3 x D# Ni-MH rechargeable battery with a capacity of 5000-8000 mA/h

Close the compartment. Switch on the device at the rear side of it, either on LOW or HIGH mode. The green light starts to flash. Place the tool on the highest shelf in the refrigerator for the best efficiency. The green light indicate that Philip is working normally, when the light turns to red, please change or recharge the batteries.

Attention:
Don't put Philip onto a wet or hot surface. Remove the battery, if you don't use Philip for a long time. A flashing red light shows that you have to change the battery.

Setting:
Refrigerators up to 250L - LOW Modus
Refrigerators over 250L – High Modus recommended
The integrated microcomputer controls automatically the ozone and ions production. **LOW mode:** the appliance works first for one hour and then turns off automatically for 3 hours and switches on again in an endless circle of 4 minutes every 4 hours. **HIGH mode:** the appliance works first for four hours and then turns off automatically for 3 hours and switches on again in an endless circle of 8 minutes every 4 hours.

Cleaning/Maintenance:
Change of batteries: Philip's light is blinking red when the batteries have to be replaced or recharged.

- Replace the alkaline batteries with similar one
- Recharge the batteries with the adapter provided.

Take Philip out of the fridge, turn it off and wait a little bit in order that the appliance gets the room temperature. Now you can plug in Philip with the adapter cable into the socket. The blinking light is red and informs you that

recharge process has begun. The recharge time is about 15 hours. When the red light turns to green, the recharge process is finished and you can replace Philip in its function. Clean the metal grip once a month. Take Philip out of the refrigerator, turn it off and let it get room temperature. Pull up the grip to remove it. Clean both sides of the grip and the needles. Reassemble all parts; the appliance is ready-to-operate again.

IMPORTANT:

- Do not insert any metallic objects into the unit to prevent electrical shocks and damage. Do not place the unit close to inflammable and explosive objects.
- Do not expose **AIRBUTLER** Philip in direct sunlight or steam.
- **AIRBUTLER** Philip should not be in contact with water.
- Do not use alcohol or benzene for cleaning the casing to avoid any damage on the surface.
- Keep appliance out of reach of children and pets.

Accessories:
1 adapter 230 V

Technische Daten:

Type	**AIRBUTLER** Philip
Voltage	4,5 V / 3 x D# Batteries
Power consumption	1,5 W
Negative ions	> 2 x 10^6
Active oxygen	< 0,15 ppm
Dimension	110 x 64 x 135 mm
Weight	300 g
Refrigerators up to	450l

AIRBUTLER reserves the right of any technical modifications of the appliance.

We are at your service for questions or application problems:
office@airbutler.com

AIRBUTLER®
Homecare

Warranty for PHILIP

1. All **AIRBUTLER** products are subjected to stringent testing before they leave the factory. Guarantee of function for two years from date of purchase.

2. Damage and malfunctions within the warranty period are only dealt with on presentation of the completed warranty certificate. Please return the appliance to the trader so that the cause of malfunction can be identified. If the damage or malfunction is due to a production fault then the appliance will be repaired immediately or replaced with a new appliance. Damage which is not due to a production fault cannot be taken into account.

3. The warranty does not include any damage due to incorrect handling, faulty reassembly, manual conversion in or on the appliance, omission of cleaning, exterior damage to the appliance or obvious damage to the interior of the casing (such as e.g. lightning, artificial cause or natural events).

4. The date on the warranty certificate and submission of the bill are imperative for any warranty claims.

Name: _____

Address: _____

Purchase date: _____

Phone: _____

Stamp of trader: _____